

# Steps for Mould Remediation In Private Homes

Mould growth is common in water-damaged homes and buildings. Because exposure to indoor mould growth can result in various health hazards (including difficulty breathing, skin rashes and nose, eye and throat irritation), it's important to remove mould-damaged materials and repair mould damaged-areas quickly and safely.

Whether you choose to hire a contractor to address the mould concerns in your home, or complete this work yourself, it is important these key mould remediation steps are understood and followed:

## ***IMPORTANT STEPS FOR MOULD REMEDIATION***

Before starting any remediation or construction work on walls, be sure you know which walls are load-bearing, and consult a contractor for guidance on structural safety.

### ***1. Conduct a visual inspection of the damage.***

Wear gloves and an N-95 respirator (available at most hardware stores). Assess the mould growth to determine the extent and materials that are affected.

Be sure to check items like carpet, drywall and structural wood.

A contractor is recommended if more than 10 square feet of mould growth is noted.

### ***2. Remove mouldy materials in sealed plastic bags, whenever possible.***

Check with your municipality about the collection of flood-damaged and mouldy items. Wear personal protective equipment including gloves, boots and an N-95 respirator mask, and remove and dispose of wet floor coverings, furniture and other soft materials.

Remove and dispose of drywall that have been soaked or that have absorbed water.

### ***3. Clean, sanitize, and assess items for possible salvage and repair.***

Clean all household surfaces using warm water and soap.

Then, sanitize all surfaces using a mild bleach solution (one tablespoon of bleach to four litres of water).

Assess items that might be safe for salvage & repair, including:

- Surfaces that DO NOT absorb water.
- Fabrics that can be laundered and bleached.
- Surfaces not affected by water.

Additional information about safe clean-up and detailed guidance about items to discard or salvage is provided in the [Cleaning the House After a Flood](#) document available at

[https://myhealth.alberta.ca/alberta/Alberta%20Images/abflood2013/Cleaning\\_the\\_House\\_After\\_a\\_Flood.pdf](https://myhealth.alberta.ca/alberta/Alberta%20Images/abflood2013/Cleaning_the_House_After_a_Flood.pdf).

**4. Hire a professional to inspect and clean the furnace and ducting, hot water tank exhaust, and fireplace before use.**

Fire-fighting water and chemicals may contain harmful microorganisms that can grow on surfaces inside your heating and ventilation ((HVAC) systems.

The professional hired should:

- Isolate sections of HVAC systems that are being cleaned using plastic sheeting or other vapour barriers.
- Replace all water damaged materials, like insulation and filters.
- Vacuum, clean and sanitize all surfaces. All components must be dried as quickly as possible.
- Test that the HVAC system is operating properly.

**5. After completing steps one through four, continue with your renovations.**

Remember that any new construction should not be closed until after all structural components are dry.

**Contact Alberta Health Services, Environmental Public Health, North Zone at 780-791-6078 if you have questions about mold remediation.**

**For more information, please contact your nearest Environmental Public Health office.**

Edmonton Main Office  
Calgary Main Office  
Lethbridge Main Office

780-735-1800  
403-943-2288  
403-388-6689

Grande Prairie Main Office  
Fort McMurray Main Office  
Red Deer Main Office  
[www.ahs.ca/eph](http://www.ahs.ca/eph)

780-513-7517  
780-791-6078  
403-356-6366

FIRE-16-012  
Created: May/16  
Updated: Jul 29/16  
10:06