

# Random Urine Toxicology Collection - Male (LTR71415)

Last Approved Time: 11/11/2022

Revision: 2.30

Following the instructions below is important for providing you with accurate test results.

Specimen will **not** be tested if label or requisition is missing information.

John Doe  
12345 6700 Date  
Jan 3  
Time 9:00am



1. Make sure the cup is labelled with **all** of the following:
  - Full first and last name
  - Healthcare number
  - Date and time of collection



2. Wash your hands with soap and water.
3. Dry your hands, using paper or cloth towel, if possible.



4. Remove the lid from the container.
5. Place the lid **upside down** on a counter.

**Do not touch the inside of the cup with your fingers**



1. Urinate (pee) into the cup until it is  $\frac{1}{4}$  to  $\frac{1}{2}$  full. Then stop.
2. Finish urinating into the toilet.

**Do not overfill the cup**



1. Secure the lid on the cup.
2. Place the cup in the designated area or give to a laboratory staff member.
3. Wash your hands with soap and water.

**Note:** This specimen cannot be collected at home.