# **Standard Operating Procedure**

# Contingency Plan Loss as a Result of Steam, Water or Other Utility Interruption

Document #: A1.17 Initial effective date: October 2017 Last updated: February 2020 Next review: February 2023

# **OBJECTIVES**

- Outline response required in the event of an emergency situation that would disrupt water and other utility systems.
- Ensure MDR operations are maintained in order to support the patient care units and departments requiring reprocessed instruments and supplies.
- Identify roles and responsibilities of MDR staff during planned and unplanned water and other utility disruption.

#### APPLICABILITY

Compliance with this document is required by all Alberta Health Services employees, members of the medical and midwifery staff, students, volunteers, and other persons acting on behalf of Alberta Health Services (including contracted service providers as necessary) working within Medical Device Reprocessing.

#### **ELEMENTS**

- 1. Planned water or other utility loss
  - 1.1 MDR management will be notified of an upcoming disruption by site Facilities Engineering and Maintenance (FM&E).
  - 1.2 FM&E, in collaboration with the MDR, will schedule the shutdown to occur when the MDR is operating at nonpeak hours, reducing the impact on reprocessing.
  - 1.3 If the disruption in service will impact units and department the MDR Manager or designate will:
    - a) notify next level of management (operating Room Manager, Site Administrator, and Director).
    - b) notify the units and departments affected and identify instruments that must be available for use.
    - c) identify with site Contracting, Procurement and Supply Management (CPSM) department which supplies and instruments can be replaced with disposable options.
    - d) consult with other sites to determine where supplies and instruments can be sent for reprocessing during shutdown.

Original date: October 2017 Revised date: February 2020



# Contingency Plan Loss as a Result of Steam, Water or Other Utility Interruption | 2

- e) consult with affected units and departments to determine if any sterile instruments or supplies can be borrowed from other sites.
- f) coordinate transport of instruments and supplies to/from supporting site(s) as per specific procedure.
- g) evaluate staffing needs and schedule additional staff as required.
- 2. Unplanned water and other utility loss
  - 2.1 The MDR Manager or designate will be notified as soon as a disruption with the water system is noted by MDR staff.
  - 2.2 MDR staff will continue to assemble available instruments and supplies for sterilization.
  - 2.3 MDR Manager of designate will consult with FM&E to determine the extent of loss of service, impact to affected units and departments, and how to resolve the problem.
  - 2.4 If the disruption in service will impact units and departments the MDR Manager or designate will:
    - a) notify next level of management (Operating Room Manager, Site Administrator, and Director). This level of management will determine if cancelling procedures is required.
    - b) notify the units and departments affected and identify instruments that must be available for use.
    - c) identify with site CPSM department which supplies and instruments can be replaced with disposable options.
    - d) consult with other sites to determine where supplies and instruments can be sent for reprocessing during shutdown.
    - e) consult with affected units and departments to determine if any sterile instruments or supplies can be borrowed from other sites.
    - f) coordinate transport of instruments and supplies to/from supporting site(s) as per site specific procedure.
    - g) evaluate staffing needs and schedule additional staff as required.
- 3. Water and other utility system resumes operations
  - 3.1 The MDR Manager or designate will:
    - a) MDR staff will perform any required operational requalification (as per equipment manufacturer's instructions).
    - b) notify affected units and departments that service will be resumed.
    - c) identify resource requirements to catch up with backlog of instruments and supplies that require reprocessing.
    - notify supporting site(s) and identify if further support is needed to ensure adequate inventory while backlog of instruments and supplies are being reprocessed.



#### Contingency Plan Loss as a Result of Steam, Water or Other Utility Interruption | 3

- 4. Documentation
  - 4.1 The Manager, or designate, will document unplanned disruption in the Reporting and Learning System (RLS) and will include:
    - a) date and time of disruption;
    - b) steps taken to resolve the issue(s);
    - c) cause of disruption, for example, system error, user error;
    - d) impact to affected units and departments.

#### DEFINITIONS

#### None

# REFERENCES

- Alberta Health Services governance documents
  - AHS Calgary Zone (2008) Business Continuity Plan: Loss of Normal Water Supply and/or Unsafe Water Supply.
- Non-Alberta Health Services documents
  - Canadian Medical Device Reprocessing. (Canadian Standards Association) (CAN/CSA Z314-18)

#### **VERSION HISTORY**

Date	Action taken
October 2017	Initial approval
February 2020	Last updated
February 2023	Next revision date

