

Transportation of Contaminated Medical Devices

Central Zone Infection Prevention and Control (IPC)

Note: This Information Sheet was developed by the Central Zone IPC Program and MDR. If you have any questions or concerns regarding this information sheet please contact your local MDR Lead or ICP.

Medical devices with the potential for delayed reprocessing shall have gross debris removed at point-of-use.

1. **Don appropriate personal protective equipment (PPE).**
2. **Remove gross debris** (i.e., blood clots or tissue) by immersing instruments in water in a designated sink or container. **Do not** rinse under running water.
3. **Spray with Pre-Klenz™** according to the manufacturer's instructions to prevent the soil drying on the instruments.

For off-site reprocessing: place instruments in plastic bag and place in a covered leak-proof transport container. Container must be clearly marked "dirty/soiled".

For on-site reprocessing: place instruments in a covered leak-proof container that is clearly marked "dirty/soiled".

Transport staff will collect and deliver to the Medical Device Reprocessing (MDR) area for reprocessing.

REMINDER: Clean/disinfect environmental surfaces and perform hand hygiene.

How To Use PRE-Klenz™ Transport Gel



Step 1
Place soiled instruments in tray.
Ensure that all instruments are open.

Step 2
Turn nozzle to "Spray" position.

Step 3
Apply 5-10 sprays per tray.

Step 4
Instruments are now ready for transport.

STERIS
Document # M2264EN.2004-05, Rev. A
IPSE Printed 04/2006, 2500
©2002-2006 by STERIS Corporation
All rights reserved. Printed in the USA.

Transportation of Contaminated Medical Devices | 2

References

Alberta Health Services. Medical Device Reprocessing. (2018 Jan). Transport and Distribution of Soiled and Sterilized Medical Devices within the Health Care Facility (MDR-04-89).

<https://insite.albertahealthservices.ca/main/assets/policy/clp-dthr-surgical-mdr-04-89-ipc-transport-distn-within-hc-facility.pdf>

Alberta Health Services. Medical Device Reprocessing. (2018 Jan). Transportation and Distribution of Soiled & Sterilized Medical Supplies (Off-site) (MDR-04-84).

<https://insite.albertahealthservices.ca/main/assets/policy/clp-dthr-surgical-mdr-04-84-ipc-trans-distrib-soiled-sterilized-med-supplies.pdf>

Canadian Standards Association. Z314.18 (R2018). Canadian medical device reprocessing. 1st Edition. Available from: AHS Knowledge Resource Services <https://KRS.libguides.com/ipc/csa>